

**SPRING SEAT
FITMENT
FOR COIL SPRING
SUSPENSION**



SPRING SEAT

IMPORTANT

The groove inside the bottom of the spring seat **MUST** be placed facing downwards (as shown in the diagram) so that it covers the circlip when fitted.

CIRCLIP

